Servo & Control

Prof. Jamie Paik
Alihan Bakir
Reconfigurable Robotics Laboratory
EPFL, Switzerland







Topics

- Actuation systems
- Servo motors
 - Principle
 - Send data

- Control loop
- Servo control demo





Actuation systems

- Combustion
- Hydraulics
- Pneumatics
- Electric
- Thermal








Types of electric actuators

- Electric motors
- Solenoids
- Piezoelectric
- Shape memory alloys














Types of electric motors


- Brushed DC motors
- Brushless DC motors
- Stepper motors
- Servomotors
- AC induction motors
- AC synchronous motors
- Universal motors






DC motor concept









Servomotors

- DC motor with integrated **position/speed** control
- 3 main components:
 - DC motor
 - Gear box
 - Sensor and control circuit












Servomotors

• 3 main components








Servomotors

- Many different shapes and specs
 - Continuous rotation
 - Speed controlled
 - Limited rotation
 - Position controlled
- Torque: 20kg = 20kg.cm
- Rotation: 180, 270, cont. etc.
- PWM: 50Hz






Servomotors

- Limited rotation
 - Position controlled
- Check datasheet
 - 0-180
 - 0-270

Pulse Width Range

Neutral Position

Running Degree




Servo Motor PWM Timing Diagram



Servomotors

- Continuous rotation
 - Speed controlled




Servo Motor PWM Timing Diagram



- How do servos control speed/position?
 - PID loop
- What is a PID loop?
 - A feedback control loop
- Where else?
 - Temperature apartment, office, fridge, AC
 - Position car steering, RC plane flaps, drones
 - Flow, pressure etc.
 - Speed Conveyor belts, electric cars






ME-420 Advanced design for sustainable future




- P responds to current error
- I responds to accumulation of past errors
- D responds to **future errors** (current rate)








- Proportional (P) term
 - K_p * error
- Integral (I) term
 - $K_i * \int error dt$
- Derivative (D) term
 - $K_d * \frac{\partial error}{\partial t}$





- How to determine the performance of your system?
- Step response



ME-420 Advanced design for sustainable future





What actually P term does to a system?


Proportional to error!

Decrease: Rise time, Settling time,

Steady-state error

Increase: Overshoot

Set point
 High K_p
 Medium K_p
 Low K_p








• I term?

Decrease error accumulation!

Decrease: steady-state error

Increase: Overshoot, Settling time








• D term?

Decrease overshoot!


Decrease: Overshoot,
Settling time







• In short:







- Proportional (P) term
 - K_p * error
- Integral (I) term
 - $K_i * \int error dt$
- Derivative (D) term

•
$$K_d * \frac{\partial error}{\partial t}$$

Numerically

- Proportional (P) term
 - K_p * error
- Integral (I) term
 - $K_i * \sum (error * \Delta t)$
- Derivative (D) term

•
$$K_d * \frac{\Delta error}{\Delta t}$$

- Error = Reference Measured
- Challenge? Discrete





- Check Youtube
- Ask ChatGPT
- Come to the office hour tomorrow

Demo!