

Scanning Electron Microscopy (SEM)


CH-633




Learning Outcomes

How the SEM works?

What type of information we can obtain from looking at the SEM images?








Why these two SEM images from identical locations are different?

Learning Outcomes


What can this information tell us?







How can we use it to interpret the images?





And how do we tune the microscope parameters to obtain the specific information we are seeking?

Contents

mad Oveisi

- SEM setup
- Imagining with SEM
 Operation, Signals
 Contrast mechanism
 Interpretation of images
 Challenges and artefacts

- Related techniques
- Image Quescussion (requires interaction and your input)

≣mad Oveisi

What is an SEM

Scanning Electron Microscope (SEM) is an instrument for observing and analyzing the surface structure of a bulk sample using a finely focused probe that scans the sample in raster.

1st electron microscope (TEM) in 1933 by Ernst Ruska (1986 Nobel Prize in Physics)
 The first true SEM was described and developed in 1942 by Zworykin
 1st commercial SEM in 1965 by the Cambridge Scientific Instruments Mark I "Stereoscan"



Teneo, TFS

Primary applications:

- Surface topography and morphology; in life and materials sciences
- Composition analysis (e.g. EDX or WDX)
- Crystallography (e.g. EBSD)
- Optical and electronic properties (e.g. Cathodoluminescence), and more ...


SEM can achieve 1-5 nm resolution, depending on the instrument and the imaging condition being used.



Coloured image of fruit fly mutant

Why fast electrons?

SEM





Compared to light microscopy, SEM offers:

- · Better resolution; shorter wavelength of electrons
- Better depth of field (i.e. how much of depth is sharp = in focus); lower convergence angle of the electron beam, in the order of mrad

How SEM works?

The whole system is kept under high vacuum

Electrons gun generates electron and accelerates them to high speed (energies).


Electron will go though the 1st lens system to form a the smallest possible probe of desired current (i.e. number of electrons / time / surface area)

2nd lens system focuses and scans the probe on sample

Electrons interact with the sample and different signals are generated

Various detectors surrounding sample collect radiated signals for each scan point to form an image
→ Image is formed point by point

Components of the SEM | Vacuum system



Why we need a vacuum system?

- 1. Electron propagation is only possible through vacuum (e⁻ interacts heavily with the matter)
- 2. A good vacuum system is crucial to reduce contamination and surface modification


Vacuum system

Electron gun
Electron optics
Detectors

Vacuum system has to be VERY clean:

- Clean samples, not dusty or oily or other solvents
- Use gloves to handle the sample

Components of the SEM | Electron gun



Vacuum system
Electron gun
Electron optics
Detectors


Purpose: To create a narrow intense beam of electrons

Electrons can be released by heat or an electric field

3 types of electron guns:

- Thermionic gun (Thermal)
 Heat only
- Cold field emission gun (cold FEG)
 Electric field: Potential (voltage) difference
- Heat assisted field emission gun: Schottky emitter Heat + Electric field

Components of the SEM | Electron optics



Vacuum system
Electron gun
Electron optics
Detectors

Purpose:

In the SEM we use lenses (condenser system) to:

- 1- condense the electron beam into a fine probe (defines probe size and current);
- 2- focus the probe on the sample (objective lens | e.g. final lens)

Scan coils raster scan the beam over the sample

Electrons pass through a series of lenses and apertures

The smaller the probe size, the better the resolution, but the lower the probe current (number of electrons that hit the sample)

Emad Oveisi



Components of the SEM | Electron optics

- Lenses for light
 - Glass or polymer lenses
 - Deflection of light through changing refraction index

Oil-Immersion Infinity-Corrected Apochromat Objective



- Lenses for electrons
 - Variable focus
 - Electrostatic
 - Electromagnetic: Lorentz force



Components of the SEM | Electron optics

SEM techniques

In SEM, the lens system is used to de-magnify the image of the beam source and to focus the beam on the specimen.

Components of the SEM | Detectors

Vacuum system
Electron gun
Electron optics

Detectors

Purpose:


To "see" the electrons, means create signal that is proportional to the number of electrons emanating from the sample at each scan position


Scan coils, detector and display (monitor) are synchronized

There exist detectors for electrons, x-ray, etc.

Two typical electron detectors for the SEM:

- Scintillator/Photomultiplier Everhart-Thornley detector
- Semiconductor detector
 Silicon diode with a p-n junction





1534x1024 Pixels Frame time 13.4 Sec






Image is made of pixels of different grey level



Beam locations on the specimen



Area scanned on the screen

Information transfer f(x,y,S)

- Image formed step by step by the sequential scanning of the sample with the electron probe (using pair of deflector or scan coils, controlled by the scan generator)
- Monitor and scanning coils are synchronized
- Intensity of each pixel is proportional to signal received (collected SE/BSE electrons)
- When changing the magnification, we just change the raster size (no change in optics)

Emad Oveisi

e- matter interactions


Inelastic events: The result is a **transfer of beam energy** to the specimen atom (**energy loss**) and a potential expulsion of an electron from that atom as a **secondary electron (SE)**.

If the vacancy due to the creation of a secondary electron is filled from a higher level orbital, an X-Ray or Auger characteristic of that energy transition is produced.




That's why TEMs are shielded!

Characteristic X-rays elemental map



Chemical composition

Secondary electron SEM image



Topography

u grid treated with


SEM techniques

e- matter interactions

Elastic events occur when a beam electron interacts with the electric field of the nucleus or electron cloud of a specimen atom (Coulomb forces), resulting in a change in the direction of the beam electron **without a significant change in the energy** of the beam electron (< 1 eV).


Coulombic interaction within the electron cloud, Low-angle scattering Coulombic attraction by the nucleus, Higher-angle scattering

Larger nucleus → More backscattering



Mass contrast
Backscattered SEM image

Characteristic X-rays elemental map





Chemical composition

SEM techniques

Emad Oveisi


How an SEM image is generated?





Assuming the size of the indicated particle on your screen is 2 cm, what is the magnification of the image?

- a) 35.46 kX
- b) 500 kX
- c) 100 kX
- d) 200 nm




Assuming the size of the indicated particle on your screen is 2 cm, what is the magnification of the image?

- a) 35.46 kX
- b) 500 kX
- c) 100 kX
- d) 200 nm


SEM techniques



Sample




Scan step (i.e. pixel size) on the sample?




Scan step (i.e. pixel size) on the sample?

Monitor




Pixel size on the screen?




Pixel size on the screen?

Sample 100 nm




Scan step (i.e. pixel size) on the sample? = 10 nm




Scan step (i.e. pixel size) on the sample = 5 nm

Monitor



Pixel size on the screen? = 1 cm



Pixel size on the screen? = 1 cm

Magnification = $10^{-2} / 10^{-8}$ = 1 MX

Magnification = $10^{-2} / 5.10^{-9}$ = 2 MX

What happens to resolution?

Imaging parameters

Parameters affecting Resolution (and Visibility)

Fundamental


- Electron wavelength (beam energy) and diffraction limit: → Rayleigh criterion
- Aberrations: enlarges the probe size

Probe size (or spot size) means the diameter of the final beam at the surface of the specimen

Operational and sample

- Pixel size = scan step size
- Probe size (also defines probe current and affects visibility)
- Visibility:
 - Scan speed (i.e. dwell time) and "signal to noise ratio"
 - Contrast
- Type and depth of emitted electrons signal
- System/Specimen stability → Challenges (charging, contamination, beam damage)

Resolution | Pixel size




Nyquist sampling (f) = d/2, where "d" is the smallest object, or highest frequency

Thus, the imaging sample rate (or pixel) size should be roughly half the size of the smallest object you wish to observe; e.g. if you need 100 nm resolution, then scan every 50 nm (at least).


Resolution | Probe size


Emad Oveisi





If a smaller probe has the potential to provide a higher resolution image, why is the smallest possible probe not always utilized?

Resolution | Probe size










Rayleigh criterion $\rho_d = 0.61 \lambda / \alpha$



Resolution limit

A small probe diameter comes with a decrease in probe current:

means less electrons that impinges upon the specimen and generates the various imaging signals

-> Less signal to noise ratio: indirectly affects resolution (visibility issue)

Imaging parameters

Emad Oveisi

Parameters affecting Resolution (and Visibility)


- Fundamental
 - Electron wavelength (beam energy) and diffraction limit: → Rayleigh criterion
 - Aberrations: enlarges the probe size


Probe size (or spot size) means the diameter of the final beam at the surface of the specimen

Operational and sample


- Pixel size = scan step size
- Probe size (also defines probe current and affects visibility)
- Visibility:
 - Scan speed (i.e. dwell time) and "signal to noise ratio"
 - Contrast
- Type and depth of emitted electrons signal
- System/Specimen stability → Challenges (charging, contamination, beam damage)

Visibility and "signal to noise" ratio






High signal to noise ratio



Low signal to noise ratio




How to improve signal to noise ratio?

Visibility and "signal to noise" ratio


Visibility and "signal to noise" ratio

Effect of beam current





Possible charging or sample damage

Effect of pixel dwell time




Sample drift may become the limiting factor





Emad Oveisi

Visibility and contrast



Do not throw away the information

If the detector's brightness and contrast are not properly adjusted, then it is not possible later to correct with image processing; i.e. over/under saturation problem

Emad Oveisi

Imaging parameters

Parameters affecting Resolution (and Visibility)

Fundamental

- Electron wavelength (beam energy) and diffraction limit: → Rayleigh criterion
- Aberrations: enlarges the probe size

Probe size (or spot size) means the diameter of the final beam at the surface of the specimen

Operational and sample

- Pixel size = scan step size
- Probe size (also defines probe current and affects visibility)
- Visibility:
 - Scan speed (i.e. dwell time) and "signal to noise ratio"
 - Contrast
- Type and depth of emitted electrons signal
- System/Specimen stability → Challenges (charging, contamination, beam damage)

SEM signals


- Type of signal
 - Secondary and backscattered electrons
 - X-ray, Cathodoluminescence, etc.

- Where the signal is generated
 - Depth
 - Spatial resolution

- How the signal is detected
 - Detector position/type → Signal selection
 - Energy/type selection → Affects spatial resolutions

SEM signals | Electron signals

Incident electrons interaction with the sample produces:



Electron signals:

Secondary electrons SE

Electrons ejected from the conduction or valence bands of the target atom: low energy $\approx 5-50 \text{ eV}$ Free electrons: not associated with a specific atom and contain no specific elemental information Can only escape if they are near the specimen surface \rightarrow **Topography**

Backscattered electrons BSE

Incident electrons that scatter (elastically or inelastically) and leave the sample Energy range from 50 eV to an energy close to initial energy eV $_0$ Most backscattered electrons retain at least 50% of the incident beam energy. Yield depends on the atomic number \rightarrow **Z-contrast**


Auger electrons

If the electrons are ejected from an inner shell by the energy released when an ionized atom returns to the ground state, then these SEs are called Auger electrons.

Ejected electrons with an energy characteristic of target elements → surface spectroscopy Not detected in conventional SEM

SEM signals | Other signals

Incident electrons interaction with the sample produces:



Other signals:


Electromagnetic radiations:

- X-rays with continuous energy, resulting from deceleration of incident electrons ("Bremsstrahlung" or "breaking radiation")
- Characteristic X-rays with a distinct energy associated to the target atoms.
- Cathodoluminescence: Visible radiation mainly emitted by insulating or semi-conducting materials.

Others:


- Absorbed current, electron-holes pairs creation, EBIC
- Plasmon
- Sample heating (phonons)
- Radiation damages: chemical bounding break, atomic displacement (knock-on) damage


SEM signals Where they come from



SEM signals And their energy

Energy spectrum of electrons <u>leaving the sample</u>





BSE: $50 \text{ eV} < E_{BSE} < E_0$


What is the source of the prominent peak in the low-energy region of the spectrum?


BSE energy range: BSEs follow trajectories which involve very different distances of travel in the specimen before escaping. The energy range for BSEs is thus wide (from 50 eV to that of the incident beams energy). The majority of BSEs, however, retain at least 50% of the incident beam energy (E_0) .

Generally speaking, higher atomic number elements produce a greater number of higher energy BSEs and their energy peak at the higher end is better defined.

SEM signals And their energy

Energy spectrum of electrons <u>leaving the sample</u>






The most important characteristic of SE is their extremely low kinetic energy, as the transfer of kinetic energy from the primary electron to the SE is relatively small. After ejection, the SE must propagate through the specimen while undergoing inelastic scattering, which further decreases their kinetic energy.

SE <u>are generated along the complete trajectory of the beam electron within the specimen</u>, but only a very small fraction of SE can reach the surface and escape → SE is mainly a Surface signal

SEM signals Where they come from



Surface signals:

- Secondary electrons (topography)
- Auger electrons (electronic states, chemistry)

Sub-surface signals:

- Backscattered electron (Z contrast, crystallographic information)
- Characteristic X-ray (compositional information)
- Secondary florescence (Cathodoluminescence, band-gap)

Spatial resolution depends on the size of the interaction volume

Interaction volume differs with material, beam energy (depth and widening), and spot size (widening)

Monte-Carlo simulations (Details in MSE636)

SEM signals Where they come from


The higher the beam energy,


The longer the scattering MFP, so the less the rate of energy loss with distance travelled Electrons entre the specimen with more energy and lose it at lower rate.

The trajectories near the surface become straighter,

So, the more the penetration depth (i.e. larger interaction volume)

Cumulative effects of multiple elastic scatterings cause some electrons to propagate and back towards the surface, thus widening the interaction volume.








SEM signals Where they come from


Effect of the accelerating voltage (beam energy) on penetration depth and signal





20 kV:

Strong penetration: It reveals the copper grid under the C film via the electron backscattering, but the structure of the film itself is hidden





2 kV:


Low penetration,
Only a few electrons reach the copper grid and most of the signal is produced in the C film. The C film and its defects become visible

SEM signals Where they come from

Effect of the accelerating voltage (beam energy) on penetration depth and signal







3 kV:

It reveals the perovskite grains, but the structure of the covering HTM layer (FA-CN) is not visible.

1 kV:


Only a few electrons reach the peroskite layer and most of the signal is produced in the HTM layer. The HTM layer is visible


SEM signals Where they come from

The higher the atomic number "Z",

the more the probability for scattering (elastic and inelastic)
 (i.e. shorter scattering mean free path)

So, the shorter the penetration depth (i.e. smaller interaction volume).






SEM signals Where they come from


The higher the atomic number "Z",

the more the probability for scattering (elastic and inelastic)
 (i.e. shorter scattering mean free path)

So, the shorter the penetration depth (i.e. smaller interaction volume).





reaching the surface




SEM signals | Backscattered electrons










BSE yield **□** increases with "Z"


- η shows a monotonic increase with atomic number: Areas of the specimen composed of higher atomic number elements emit more backscatter signal and thus appear brighter in the image.

 This relationship forms the basis of atomic number (Z) contrast imaging with BSE.
- Z contrast is relatively stronger at lower atomic numbers (see the slope of the line).

SEM signals | Secondary electrons







There is a general rise in δ as the beam energy is decreased, primarily due to the reduction in the interaction volume.

 δ is generally regarded as being independent of Z. If there is any (still a matter of debate) then it is very small.


SEM signals | BSEvs SE imaging

Example1: Ferritic stainless substrate coated with a porous MnCo₂O₄

SE image

SE have low energies (5-50eV), and thus are emitted only from surface and possess information about topographical features.


BSE image



BSE emission depends on "Z", thus intensity in the BSE images scales with atomic number and depends on local composition

SEM signals | BSEvs SE imaging


Example 2: Dust on WC (different Z materials)



SEM technique

Why the rough particle appears brighter in the SE image?

SEM signals | Effect of sample roughness on SEyield



- If a sample is titled, the interaction volume is tilted and is closer to the surface. Thus, more SE can escape from below the surface, giving higher signals received by the detector.
- The same principle is true for rough surfaces: Sloped surfaces and edges have an interaction volume that is effectively titled and have higher SE yield.

Rough surfaces generates higher SE image signal.

Titling the specimen can change SE image contrast.

Imaging parameters

Emad Oveisi

Parameters affecting Resolution (and Visibility)

Fundamental

- Electron wavelength (beam energy) and diffraction limit: → Rayleigh criterion
- Aberrations: enlarges the probe size

Probe size (or spot size) means the diameter of the final beam at the surface of the specimen


Operational and sample

- Pixel size = scan step size
- Probe size (also defines probe current and affects visibility)
- Visibility:
 - Scan speed (i.e. dwell time) and "signal to noise ratio"
 - Contrast
- Type and depth of emitted electrons signal
- System/Specimen stability → Challenges (charging, contamination, beam damage)

Challenges | Beam damage

Beam induced changes to the sample:

- Atom displacement ("knock on")
 - Radiation damage, More severe for high beam energies
- Chemical bound breaking
 - Radiolysis
 Increasing beam energy can lessen radiolysis
- Lattice atom vibrations (phonons)
 - Sample heating




Challenges | Contamination

Hydrocarbon build-up on surface

Masks surface features and information about the sample

- Sources:
 - Sample surface
 - SEM chamber
 - Beam induced degradation and migration of sample compounds
- To avoid / minimize:
 - Use gloves when handling samples
 - Plasma cleaning sample prior to observation



Challenges | Charging


Emad Oveisi

Accumulation of negative charge Occurs in insulating samples (also in samples that are not well grounded)

Charging deflects the low-energy secondary electrons (mainly, but can affect BSE) causing


image distortions and contrast changes

- Depends on:
 - Material properties (surface resistivity)
 - Beam energy and current
 - Scan rate
- Ways to mitigate charging
 - Coat the sample with a conductive layer
 - Work at low kV
 - Use low currents (noisy images)
 - Use low-vacuum mode
 - Charge compensation devices
 - Use the "magic" charge neutrality voltage






Fiberglass





SiO₂ substrate

SEM techniques | Environmental SEM



Modified Quanta200:

- Available gases (mass flow controller) H₂, O₂, N₂, CO, NH₃, C₂H₄
- Pressure up to 800Pa (8mbar)
- Temperature up to 1000°C
- QMS Mass Spectrometer



SEM techniques | Environmental SEM

Example: SOFC anode under Redox cycling


Sample: SOFC anode made of YSZ (Yttrium Stabilized Zirconium) and Ni (which is reduced and oxidized at each cycle)


Redox Cycling between O₂ and H₂ at 800°C


emperature: 187°C Time: 3.1h

SEM techniques | Environmental SEM

Example: SOFC coated interconnect oxidation








48 hours oxidation under 33 Pa of oxygen at 880°C


Sample: SOFC interconnect made of steel and coated with Co and Cerium.

SEM techniques | Energy dispersive x-ray spectroscopy




Secondary

Characteristic X-ray




X-ray generation


X-ray energy characteristic interorbital electron transitions and thus of the element




Auger emission


The relaxing process interacts with an electron with a characteristic energy
















Strontium poisoning of stainless steel


- From beryllium up to periodic table
- Sensitivity 0.1 wt.%
- Quantitate analysis (many requirements; e.g. flat sample)
- Point, line scan, and mapping
- To excite an EDX peak, the beam energy needs to be around twice the energy of the peak
- We should consider the interaction volume
- Interaction volume increases with beam energy
- About 130 ev energy resolution for Si(Li) detector

SEM techniques | Focused ion Beam






Nano fabrication







Cross-sectioning SEM imaging



Failure analysis

Deposition







Insertion of electrical connection


mad Oversi


Site specific TEM lamella extraction
















mad Overs

3D microscopy (can be combined with other techniques, e.g. EDX, EBSD, ...)



3D microscopy: SEM/FIB + EDX





Sample: Multilayer of heterogeneous materials, e.g. Ni-YSZ/YSZ/GDC/LSCF-GDC


Studying degradation of fuel electrode/electrolyte interface, micro-cracking/delamination.

SEM techniques | Electron backscatter diffraction - EBSD

Electron backscatter diffraction is an electron diffraction technique in SEM used to obtain information about crystallographic phase, crystal orientation and defect densities.








Geometric set-up of an EBSD measurement

SEM technique

≣mad Oveisi

SEM techniques | EBSD-based orientation mapping

Measures crystal orientations on a regular grid by electron diffraction. The so-determined data are used to produce orientation (or phase maps) of the scanned area on the sample.



Lateral resolution: 20 to 100 nm (depending on the sample material).

Measurement rate currently up to hundreds of patterns per second.

Investigated areas: few µm² to few cm².

Angular resolution: 0.5° down to 0.01° with special techniques (→XR EBSD).


The technique can also be extended into a 3D technique (→ grain boundaries).

Emad Oveisi



SEM techniques 3D EBSD-based orientation mapping

3D orientation mapping of a severely deformed and recrystallized Cu-Zr alloy.




Colours correspond to the inverse pole figure position of the sample normal direction.





Wet chemical oxidation

2.5 M KOH 0.125 M (NH₄)S₂O₈ 10 min




Spray coating

PTFE + carbon black

Heating


350 °C in air for 1h




Cu_xO nanowires (electrolyte side)


Microporous layer (gas diffusion side)


Gas diffusion electrode







Compare and interpret the contrast you see in the BSE/SE images


















Discuss the changes visible in these BSE images?









Discuss the changes visible in these SE images acquired at high and low beam energies?






SEM signals Edge effect & beam energy



Emad Oveisi

SEM signals Edge effect & beam energy




Cu_xO nanowires (electrolyte side)


Microporous layer


(gas diffusion side)

Image Quescussion





Discuss the contrast difference between the images?








Emad Oveisi














IIIau Overs

Discuss the artefacts visible in some of the images.

How it has been resolved?







Resources

Emad Oveisi

 Scanning Electron Microscopy and X-Ray Microanalysis, Springer, by Joseph Goldstein et al.


Hardcopy at EPFL & CIME libraries

 Image formation in low-voltage scanning electron microscopy, Springer, by L. Reimer

Available online

 Physics of image formation and microanalysis, Springer, by L. Riemer





Optique: Fondements et applications, Dunod, by J.S. Perez