
Selected Topics in Advanced Optics

Week 13 – part 1

Olivier J.F. Martin Nanophotonics and Metrology Laboratory





Metasurfaces – A potpourri of applications







Incident light :LCP











 In analogy with Fresnel lenses, a collection of plasmonic nanostructures can produce focusing effects, or more complex beam shaping







 In analogy with Fresnel lenses, a collection of plasmonic nanostructures can produce focusing effects, or more complex beam shaping



Nano Letters vol. 12, p. 4932 (2012) Olivier J.F. Martin


 V-shaped nanostructures provide the different phases required for the lens






Nano Letters vol. 12, p. 4932 (2012) Olivier J.F. Martin


Same focus spot as a real lens



Optical vortex

 Arbitrary phase fronts can be created with such a metasurface






Science vol. 334, p. 333 (2011) Olivier J.F. Martin

Meta-holograms

 Apertures in a metal film are used to produce the different phase elements





Nature Communications vol. 4, p. 2807 (2013) Olivier J.F. Martin

Meta-holograms






Figure 4 | Simulated holographic images compared with the experimental images. (a) The simulated holographic images created by an ideal metasurface hologram with smooth phase and amplitude modulations. (b) The simulated holographic images created by a metasurface hologram with an eight-level phase modulation and a four-level amplitude modulation. (c) The simulated holographic images created by a metasurface hologram with an eight-level phase modulation and a two-level amplitude modulation. (d) Holographic images obtained experimentally from the fabricated samples. All the images are taken from the same image plane 10 μm above and parallel to the metasurface hologram.


Meta-holograms and wavelength multiplexing effects

Different apertures will produce different phases when illuminated with different

wavelengths









Meta-holograms and wavelength multiplexing effects

 The number of unit cells used to define one hologram pixel influences the hologram quality




Advanced Materials vol. 24, p. 6300 (2012) Olivier J.F. Martin

Meta-holograms and wavelength multiplexing effects




PNAS, vol. 111, p. 12679 (2014)

 Two different meta-holograms with different responses for left and right circular polarizations can be superposed on the same sample




Nature Communications vol. 6, p. 8241 (2015) Olivier J.F. Martin


Each hologram is defined using plasmonic nanostructures



Nature Communications vol. 6, p. 8241 (2015) Olivier J.F. Martin

 A different response is obtained, depending on the helicity (left or right) of the illumination






Nature Communications vol. 6, p. 8241 (2015) Olivier J.F. Martin

LiDAR


Light detection and ranging



Laser & Photonics Reviews, vol. 16, p. 2100511 (2022) Olivier J.F. Martin

LiDAR


Different implementations and principles of operation



Laser & Photonics Reviews, vol. 16, p. 2100511 (2022) Olivier J.F. Martin

LiDAR


Metasurfaces are usually used for scanning the scene



Laser & Photonics Reviews, vol. 16, p. 2100511 (2022) Olivier J.F. Martin

Art...?

Metasurfaces can also produce some interesting colorful effects



Advanced Optical Materials vol. 2023, p. 2202165 (2023) Olivier J.F. Martin

Art...? HSQ Ag/HSQ

Advanced Optical Materials vol. 2023, p. 2202165 (2023) Olivier J.F. Martin

Selected Topics in Advanced Optics


Week 13 – part 2

Olivier J.F. Martin Nanophotonics and Metrology Laboratory




Metasurfaces governed by Mie resonances

 Dielectric resonators have lower losses than plasmonic ones and are also associated with phase shifts




ACS Photonics vol. 4, p. 2638 (2017) Olivier J.F. Martin

The phase is engineered with transparent nanostructures with varying dimensions




Optica vol. 3, p. 1504 (2016) Olivier J.F. Martin

A phase shift can also be obtained using steep structures in Si




Science vol. 345, p. 298 (2015) Olivier J.F. Martin

A phase shift can also be obtained using steep structures in Si




Science vol. 345, p. 298 (2015) Olivier J.F. Martin

• Design based on TiO₂ nanofins, which orientation determines the phase response



Science vol. 352, p. 1190 (2016) Olivier J.F. Martin


Such a surface can be highly achromatic



Science vol. 352, p. 1190 (2016) Olivier J.F. Martin


Fabrication of nanofin

A very smooth surface is required, here fabrication in TiO₂




Fabrication of nanofin

A very smooth surface is required, here fabrication in TiO₂




Fabrication of nanofin

A very smooth surface is required, here fabrication in TiO₂



Metasurfaces governed by Mie resonances

 Such dielectric metasurfaces appear to have superior optical properties (at least in terms of efficiency) than plasmonic metasurfaces



ACS Photonics vol. 4, p. 2638 (2017)


- Polarimetry provides significant information on materials, objects and their interaction with light
- The polarization of light is described by the Stokes vector, which requires four different measurements

$$S_{0} = a_{x}^{2} + a_{y}^{2} = I = E_{\parallel}E_{\parallel}^{*} + E_{\perp}E_{\perp}^{*}$$

$$S_{1} = a_{x}^{2} - a_{y}^{2} = Q = E_{\parallel}E_{\parallel}^{*} - E_{\perp}E_{\perp}^{*}$$


$$S_{2} = 2a_{x}a_{y}\cos\varphi = U = E_{\parallel}E_{\perp}^{*} + E_{\perp}E_{\parallel}^{*}$$

$$S_{3} = 2a_{x}a_{y}\sin\varphi = V = j\left(E_{\parallel}E_{\perp}^{*} - E_{\perp}E_{\parallel}^{*}\right)$$




I: irradiance $I^2 \geq Q^2 + U^2 + V^2 \quad \text{in general}$ $I^2 = Q^2 + U^2 + V^2 \quad \text{for polarized light}$ $Q = U = V = 0 \quad \text{for unpolarized light}$ degree of polarization: $\sqrt{Q^2 + U^2 + V^2} / I$ (between 0 and 1) degree of linear polarization: $\sqrt{Q^2 + U^2} / I$ (between 0 and 1) degree of circular polarization: V / I (between 0 and 1)

Metasurfaces have the potential to retrieve the entire polarization state in a single




Nature Nanotechnology vol. 10, p. 937 (2015)

 Metasurfaces have the potential to retrieve the entire polarization state in a single measurement



Optics Express, vol. 30, p. 9389 (2022)


 Metasurfaces have the potential to retrieve the entire polarization state in a single measurement



Optics Express, vol. 30, p. 9389 (2022)

Polarimetry

 Metasurfaces have the potential to retrieve the entire polarization state in a single measurement



Optics Express, vol. 30, p. 9389 (2022)


Selected Topics in Advanced Optics

Week 13 – part 3






 Reconfigurable split-rings based on active cantilevers made from bimaterials and responding to a thermal stimulus




Physical Review Letters vol. 103, p. 147401 (2009)

Switchable magnetic metamaterials using micromachining




Advanced Materials vol. 23, p. 1792 (2011)

An electromechanically reconfigurable plasmonic metamaterial



Nature Nanotechnology vol. 8, p. 252 (2013)


Stretchable metasurface



Nano Letters vol. 10, p. 4222 (2010)

Responsive metasurface


- Mg reacts to hydrogen and changes its optical response
- Switching of magnesium particles to magnesium hydride and vice versa with the aid of a 10 nm catalytic Pd layer and a 5 nm Ti buffer




Nano Letters vol. 15, p. 7949 (2015)

Responsive «metasurface» built from Mg nanostructures

• The optical response changes with the H₂ or O₂ content






Nature Communications vol. 8, p. 14606 (2017)

Responsive «metasurface» built from Mg nanostructures


• The optical response changes with the H₂ or O₂ content



Nature Communications vol. 8, p. 14606 (2017)

Responsive «metasurface» built from Mg nanostructures

The optical response changes with the H₂ or O₂ content




Nature Communications vol. 8, p. 14606 (2017)

Tunable metasurfaces


• Chalcogenide phase-change materials (Ge₂Sb₂Te₅, GeTe, ...)

Change from amorphous to crystalline upon temperature cycles or pulsed

illumination



Nanophotonics vol. 9, p. 39 (2020)




Advanced Optical Materiasl vol. 7, p. 1801782 (2019)

Tunable metasurfaces


• Chalcogenide phase-change materials (Ge₂Sb₂Te₅, GeTe, ...)

Change from amorphous to crystalline upon temperature cycles or pulsed

illumination




Nanophotonics vol. 9, p. 39 (2020)




Advanced Optical Materiasl vol. 7, p. 1801782 (2019)

 Emergence of a plurality of tuning mechanism for metasurfaces, providing numerous degrees of freedom



Photonics Insights, Vol. 3, R07 (2024)


Combination with liquid crystals



 $\varepsilon_{p} = 4.5^{\circ}$

Olivier J.F. Martin


Combination with liquid crystals




 $\varepsilon_{p} = 4.5^{\circ}$

Olivier J.F. Martin

Combination with VO₂



Combination with Chalcogenides



Olivier J.F. Martin

Selected Topics in Advanced Optics


Week 13 – part 4





Lab visit

• Next week, meet us at 9:15 in ELG 240



Advanced Optics – Information for the exam

The examination will be conducted in the following manner:

- The candidate will enter the room, show her/his Camipro card
- The candidate will choose at random one of the following topics:
- 1) Material properties and optical constants
- 2) Light scattering
- 3) Optics of metals & plasmonics
- 4) Gratings, stratified media & photonic crystals
- 5) Metamaterials and metasurfaces
- The candidate will then have about 20 minutes to prepare the topic with all possible documents (course, lecture notes, books, etc...)
- After this preparation time, the student will present for about 20 minutes the topic on the blackboard and answer questions. The entire material seen during the course and the exercises can be tested during the examination

Please select your time slot for the exam on moodle!