

Geomechanics

LECTURE 2

BASIC CONCEPTS, STRESS PATHS
AND STRESS-STRAIN BEHAVIOUR

DR. ALESSIO FERRARI

Laboratory of soil mechanics - Fall 2025




V. Favero (2017)

How much do you remember from soil mechanics?

Access the QUIZZ



<https://etc.ch/R564>




- Basic concepts of continuum mechanics: REV
- Stress and strain tensors, effective stress concept
- Stress paths
- Laboratory testing: Triaxial tests

Basic concepts of continuum mechanics

REV: REPRESENTATIVE ELEMENTARY VOLUME


Basic concepts of Continuum mechanics



Opalinus Clay at different scales (Nagra 2002b)

- **Heterogeneity** of porous media at different scales
- Interpretation of the mechanics of porous media at **macroscopic scale**
- **REV: Representative Elementary Volume**
 - Smallest volume over which the value measured of a certain property is considered as representative of the whole



Basic concepts of Continuum mechanics



- Macroscopic homogeneity
vs.
Microscopic heterogeneity
- **REV**: Representative Elementary Volume
Sample dimensions $> 10 \times$ largest particles



Basic concepts of Continuum mechanics

- Microscopic heterogeneity is neglected in the **Representative Elementary Volume** (REV)
- Size of REV depends on the material and on the considered problem.



Basic concepts of Continuum mechanics

- REV allows to use Continuum Mechanics for geomaterials
- Geomechanical properties (stiffness, strength, permeability, ...) depend on the REV size.




Stress and strain tensors


STRESS AND STRAIN VARIABLES, INVARIANTS AND TENSORS

EFFECTIVE STRESS CONCEPT

Stress



Sign convention: Compressive stress is positive





Tensor definitions

- **Tensor:** mathematical entities in the form of ordered arrays or matrices.
- Tensor of rank n in a m dimensional space has m^n components.
- Here, we are dealing with Cartesian coordinates therefore $m=3$
 - Tensors of zero rank: Scalars 1 component
 - Tensors of first rank: Vectors 3 components
 - Tensors of second rank: 9 components
- Among other uses, tensors of second rank serve to describe properties of materials that differ from one direction to another, called anisotropic.
- **Invariant of a Tensor** is a quantity that does not change with coordinate system.

Stress tensor

- Stress tensor is a second order tensor with a matrix representation

$$[\sigma] = \begin{bmatrix} \sigma_{11} & \sigma_{12} & \sigma_{13} \\ \sigma_{21} & \sigma_{22} & \sigma_{23} \\ \sigma_{31} & \sigma_{32} & \sigma_{33} \end{bmatrix} = \begin{bmatrix} \sigma_x & \tau_{xy} & \tau_{xz} \\ \tau_{yx} & \sigma_y & \tau_{yz} \\ \tau_{zx} & \tau_{zy} & \sigma_z \end{bmatrix}$$



σ_{ij} : Stress on i plane along j direction

Direction of stress component

Direction of the surface normal upon which the stress acts

Stress tensor

- Stress tensor is **symmetric** due to balance of angular momentum.

$$\sigma_{ij} = \sigma_{ji}$$



- The diagonal stresses are referred to as the ***normal stresses*** whereas the off-diagonal stresses are referred to as the ***shear stresses***

$$[\sigma] = \begin{bmatrix} \sigma_{11} & \sigma_{12} & \sigma_{13} \\ & \sigma_{22} & \sigma_{23} \\ \text{(sym)} & & \sigma_{33} \end{bmatrix} = \begin{bmatrix} \sigma_x & \tau_{xy} & \tau_{xz} \\ & \sigma_y & \tau_{yz} \\ \text{(sym)} & & \sigma_z \end{bmatrix}$$

Principal stresses

- For a given stress tensor, there is a set of planes on which the stress vectors are normal to them. On these planes, the shear stresses are zero. These are principal planes and stresses normal to them are **principal stresses**.

$$[\sigma] = \begin{bmatrix} \sigma_1 & 0 & 0 \\ 0 & \sigma_2 & 0 \\ 0 & 0 & \sigma_3 \end{bmatrix}$$




- It can be shown that the three principal stresses are the characteristic values of stress tensor obtained from **characteristic equation**:

$$\begin{vmatrix} \sigma_{11} - \lambda & \sigma_{12} & \sigma_{13} \\ \sigma_{12} & \sigma_{22} - \lambda & \sigma_{23} \\ \sigma_{13} & \sigma_{23} & \sigma_{33} - \lambda \end{vmatrix} = 0$$

The effective stress concept


- The **REV** includes a **solid**, a **liquid** and a **gas** phase



Multi-phase description

Single-phase description

Effective stress for saturated media



- **Terzaghi's effective stress** (1936)

$$\sigma'_{ij} = \sigma_{ij} - p_w \delta_{ij}$$


Diagram illustrating the components of Terzaghi's effective stress equation. The equation is shown in a box. Below the box, three red brackets indicate the components: σ_{ij} (Total stress), p_w (Pore water pressure), and δ_{ij} (Kronecker delta).

- **Assumptions**

- Fully saturated granular material
- Incompressible fluid and grains

- **All measurable effects produced by a change in the state of stress are due to a change in the effective stress** (Terzaghi, 1936)

Effective stress for saturated media



- Extended effective stress

$$\sigma'_{ij} = \sigma_{ij} - \alpha p_w \delta_{ij}$$

$$\alpha = 1 - \frac{K_{SK}}{K_S} \quad \text{Biot's coefficient}$$

- Terzaghi's effective stress (1936)

$$\sigma'_{ij} = \sigma_{ij} - p_w \delta_{ij}$$

K_{SK} : bulk modulus of the dry material

K_S : bulk modulus of the solid particles

Soils: $K_{SK} \ll K_S$ and $\alpha = 1$

Tensorial form of effective stress

- Terzaghi's effective stress: $\sigma' = \sigma - p_w$
 - And in tensorial form $\sigma'_{ij} = \sigma_{ij} - p_w \delta_{ij}$
- Kronecker Delta $\delta_{ij} = \begin{cases} 0 & i \neq j \\ 1 & i = j \end{cases}$

$$\begin{bmatrix} \sigma'_{11} & \sigma'_{12} & \sigma'_{13} \\ \sigma'_{12} & \sigma'_{22} & \sigma'_{23} \\ \sigma'_{13} & \sigma'_{23} & \sigma'_{33} \end{bmatrix} = \begin{bmatrix} \sigma_{11} & \sigma_{12} & \sigma_{13} \\ \sigma_{12} & \sigma_{22} & \sigma_{23} \\ \sigma_{13} & \sigma_{23} & \sigma_{33} \end{bmatrix} - \begin{bmatrix} p_w & 0 & 0 \\ 0 & p_w & 0 \\ 0 & 0 & p_w \end{bmatrix}$$

Stress variables

Mean total stress

$$p = \frac{\sigma_1 + \sigma_2 + \sigma_3}{3}$$

Mean effective stress

$$p' = \frac{\sigma_1' + \sigma_2' + \sigma_3'}{3}$$

Deviatoric stress





$$q = \sigma_1 - \sigma_3$$

Mean stress

$$s = \frac{\sigma_1 + \sigma_3}{2}$$


Maximum shear stress

$$t = \frac{\sigma_1 - \sigma_3}{2}$$



Stress invariants

- The stress tensor matrix representation depends on the system of coordinates we choose, while the tensor itself does not change.
- When studying deformations, we typically change the system of coordinates.
- We need to find some functions of stress tensor that do not change with the choice of coordinate: **invariants of stress tensor**.



Stress invariants

- J_1 : First invariant of the principal stress tensor σ_{ij} (its trace)


$$J_1 = tr(\sigma_{ij}) = \sigma_1 + \sigma_2 + \sigma_3$$

- J_{2D} : Second invariant of the deviatoric stress tensor s_{ij}

$$J_{2D} = \frac{1}{2} tr(s_{ij}^2) = \frac{1}{6} [(\sigma_1 - \sigma_2)^2 + (\sigma_2 - \sigma_3)^2 + (\sigma_1 - \sigma_3)^2]$$

- J_3 : Third invariant of the principal stress tensor σ_{ij} (its determinant)

$$J_3 = det(\sigma_{ij}) = \sigma_1 \sigma_2 \sigma_3$$



Isotropic stress tensor


Deviatoric stress tensor

$$\sigma_{ij} = p\delta_{ij} + s_{ij}$$

$$pI = \begin{bmatrix} p & 0 & 0 \\ 0 & p & 0 \\ 0 & 0 & p \end{bmatrix}$$

$$s = \begin{bmatrix} \sigma_{11} - p & \sigma_{12} & \sigma_{13} \\ \sigma_{21} & \sigma_{22} - p & \sigma_{23} \\ \sigma_{31} & \sigma_{32} & \sigma_{33} - p \end{bmatrix}$$

Triaxial stress conditions



Cylindrical tested specimen: $h/d=2$

Applied stresses

σ_1 : Maximum principal stress

σ_2 : Intermediate principal stress

σ_3 : Minimum principal stress


Axisymmetric conditions

$\sigma_1 = \sigma_a$ Axial stress

$\sigma_2 = \sigma_3 = \sigma_r$ Radial stress

(confining stress or cell pressure)

Triaxial stress conditions



Mean (total) stress

$$p = \frac{\sigma_1 + \sigma_2 + \sigma_3}{3} = \frac{\sigma_a + 2\sigma_r}{3} = \frac{J_1}{3}$$

Mean effective stress

$$p' = \frac{\sigma'_1 + \sigma'_2 + \sigma'_3}{3} = \frac{\sigma'_a + 2\sigma'_r}{3} = \frac{J'_1}{3}$$

Deviatoric stress:

$$q = \sigma_1 - \sigma_3 = \sigma_a - \sigma_r = \sqrt{3J_{2D}}$$


Maximum shear stress:

$$\tau = \frac{\sigma_a - \sigma_r}{2}$$

Strain tensor

- The strain tensor is a symmetric tensor used to quantify the strain of an object undergoing a small 3-dimensional deformation
 - Diagonal components: relative change in length in i direction
 - Other components: shear strains, i.e., half the variation of the right angle

$$\varepsilon_{ij} = \begin{bmatrix} \varepsilon_{11} & \varepsilon_{12} & \varepsilon_{13} \\ \text{(sym)} & \varepsilon_{22} & \varepsilon_{23} \\ & & \varepsilon_{33} \end{bmatrix} = \begin{bmatrix} \varepsilon_x & \frac{1}{2} \cdot \gamma_{xy} & \frac{1}{2} \cdot \gamma_{xz} \\ & \varepsilon_y & \frac{1}{2} \cdot \gamma_{yz} \\ \text{(sym)} & & \varepsilon_z \end{bmatrix}$$




The strain variables and the sign convention

Strain variables

Volumetric strain $\varepsilon_v = \varepsilon_1 + \varepsilon_2 + \varepsilon_3$

Sign convention in geomechanics

- Compressive forces and compressive stresses are **positive**



- Compressive strains are **positive**

$$\Delta L = L_f - L_i \quad \varepsilon_i = -\frac{\Delta L}{L_i}$$

$$\Delta V = V_f - V_i \quad \varepsilon_v = -\frac{\Delta V}{V_i}$$

Example:

$$V_f < V_i$$

$$\Delta V = V_f - V_i < 0$$

$$\Rightarrow \varepsilon_v = -\frac{\Delta V}{V_i} > 0$$

Stress-strain conjugate pairs

- Work input per unit volume of element


$$\delta W = \sigma'_{xx} \delta \varepsilon_{xx} + \sigma'_{yy} \delta \varepsilon_{yy} + \sigma'_{zz} \delta \varepsilon_{zz} + \tau_{yz} \delta \gamma_{yz} + \tau_{zx} \delta \gamma_{zx} + \tau_{xy} \delta \gamma_{xy}$$

- In term of principal stresses

$$\delta W = \sigma'_1 \delta \varepsilon_1 + \sigma'_2 \delta \varepsilon_2 + \sigma'_3 \delta \varepsilon_3$$

- In term of triaxial stresses

$$\delta W = \sigma'_a \delta \varepsilon_a + 2\sigma'_r \delta \varepsilon_r$$



Triaxial stress-strain conjugate pairs

$$\delta W = \sigma'_a \delta \varepsilon_a + 2\sigma'_r \delta \varepsilon_r$$

$$\delta W = \underbrace{\delta W_v}_{\text{Change in volume}} + \underbrace{\delta W_q}_{\text{Change in shape}} \quad \Rightarrow \quad \delta W = p' \delta \varepsilon_v + q \delta \varepsilon_d$$

Change in
volume

Change in
shape

$$\delta W = \frac{(\sigma'_a + 2\sigma'_r)(\delta \varepsilon_a + 2\delta \varepsilon_r)}{3} + \frac{(\sigma'_a - \sigma'_r)2(\delta \varepsilon_a - \delta \varepsilon_r)}{3}$$

Mean effective stress

$$p' = \frac{\sigma'_1 + \sigma'_2 + \sigma'_3}{3} = \frac{\sigma'_a + 2\sigma'_r}{3}$$

Volumetric strain:

$$\varepsilon_v = \varepsilon_1 + \varepsilon_2 + \varepsilon_3 = \varepsilon_a + 2\varepsilon_r$$

Deviatoric stress:

$$q = q' = \sigma_1 - \sigma_3 = \sigma_a - \sigma_r$$

Deviatoric strain:


$$\varepsilon_d = \frac{2}{3}(\varepsilon_1 - \varepsilon_3) = \frac{2}{3}(\varepsilon_a - \varepsilon_r)$$

Stress paths

STRESS PATHS OF GEOMECHANICS PROBLEMS

Stress paths

- The behaviour of an element of soil to a change in the stress state depends on:
Stress path = Successive states of stress to which the soil is subjected



Examples


ESP (effective stress path): stress path expressed in terms of **effective stress**

TSP (total stress path): stress path expressed in terms of **total stress**

Drained stress path: $\Delta p_w = 0$ at the end of the stress change, any variation of pore water pressure with respect to the initial value takes place;

Stress paths

Slopes



Issues:

- Stability of the slope

Lateral Loading


- Axial extension
- Lateral compression

General procedure:

- selection of some **soil elements** representative for the problem of interest
- identification of the **stress path(s)** followed by such element(s) in the phase of interest
- carrying out of **laboratory tests** to reproduce these stress path(s).


Stress paths

Shallow foundations



Issues:

- Settlements (differential)
- Bearing capacity




Vertical Loading

- Axial compression
- Lateral extension


Stress paths

Earth retaining structure (i.e. diaphragm wall)



Stress paths

Tunnel




Issues:

- Tunnel convergence
- Stability of the excavation face

Stress paths

Embankment construction





Vertical Loading

- Axial compression
- Lateral extension

Issues:

- Pore pressure development
- Consolidation (time-dependent settlements)

Trench excavation



Vertical Unloading

- Axial extension
- Lateral compression

Issues:



- Negative pore pressure development
- Consolidation (time-dependent settlements)

Laboratory testing: Triaxial tests

STRESS-STRAIN BEHAVIOUR

How to reproduce stress paths in laboratory

Triaxial test




$$H/D \cong 2$$

Usually:

$$D = 3.8 \text{ cm}$$

$$H = 7.6 \text{ cm}$$

How to reproduce stress paths in laboratory



Controlled or Measured

- F_a : Axial force
- σ_c : Cell pressure
- d_a : Axial displacement
- d_r : Radial displacement
- p_w : Pore water pressure
- V_w : Pore water volume

Measured

- t : time


Computed

- σ_a : Axial stress
→ Axial force F_a
- σ_r : Radial stress
→ Cell pressure σ_c
- ε_a : Axial strain
→ Axial displacement d_a
- ε_r : Radial strain
→ Radial displacement d_r
- ε_v : Volumetric strain
→ Pore water volume V_w


How to reproduce stress paths in laboratory

Triaxial test

The axial and radial stress



Type of strain




Volumetric + Distorsion

Failure in shear

How to reproduce stress paths in laboratory

Stress and strain variables for triaxial tests

- Axisymmetric stress state
- The principal directions coincide with the axial and the radial ones



Mean total stress

$$p = \frac{\sigma_1 + \sigma_2 + \sigma_3}{3} = \frac{\sigma_a + 2\sigma_r}{3}$$

Mean effective stress

$$p' = \frac{\sigma'_1 + \sigma'_2 + \sigma'_3}{3} = \frac{\sigma'_a + 2\sigma'_r}{3}$$

Deviatoric stress

$$q = \sigma_a - \sigma_r$$

Maximum shear stress

$$\tau = \frac{\sigma_a - \sigma_r}{2}$$

Volumetric strain


$$\varepsilon_v = \varepsilon_1 + \varepsilon_2 + \varepsilon_3 = \varepsilon_a + 2\varepsilon_r$$

Deviatoric strain

$$\varepsilon_d = \frac{2}{3}(\varepsilon_a - \varepsilon_r)$$

How to reproduce stress paths in laboratory

Drained and Undrained conditions



DRAINED CONDITION

- Water Flow **ALLOWED**
- Excess pore water pressure **dissipates**

- Long term analysis in low permeable geomaterials (clays)
- Almost all analyses in high permeable geomaterials (gravels, sands)

UNDRAINED CONDITION

- Water Flow **NOT allowed**
- Excess pore water pressure **build-up**

- Short term analysis in low permeable geomaterials (clays)

How to reproduce stress paths in laboratory

Drained conditions

- Drainage valves are **open**
- The specimen experiences volume changes $\epsilon_{vol} \neq 0$

CONTROLLED

- p_w
- ϵ_a
- σ_r

MEASURED


- ΔV_w
- σ_a

COMPUTED

- ϵ_{vol} from ΔV_w
- $\epsilon_r = \frac{(\epsilon_{vol} - \epsilon_a)}{2}$

Effective stress path (ESP) and total stress path (TSP) are parallel (displaced horizontally)

$$ESP = TSP \text{ if } p_{w,0} = 0$$



How to reproduce stress paths in laboratory

Undrained conditions

- Drainage valves are **closed**
- The specimen experiences no volume changes in saturated conditions $\epsilon_{vol} = 0$

CONTROLLED

- ϵ_a
- σ_r
- $\Delta V_w = 0 \rightarrow \epsilon_{vol} = 0$


MEASURED

- p_w
- σ_a

COMPUTED

- *ESP* from p_w and *TSP*
- $\epsilon_r = -\frac{\epsilon_a}{2}$

Effective stress path (ESP) and total stress path (TSP) are NOT parallel




How to reproduce stress paths in laboratory

Triaxial test: General procedure


0. Saturation

The pore water pressure is increased to saturate the specimen. Axial and radial stress are increased for ensuring positive effective stress.



1. Isotropic compression (IC)


Axial and radial stress are equally increased, the specimen is compressed isotropically.



Drained (C), or Undrained (U)

2. Shearing

Axial stress and radial stress are changed. The specimen is carried to failure by shearing





Drained (C), or Undrained (U)

How to reproduce stress paths in laboratory

Stress paths for shearing

Specimen led to failure in different ways



CTC: conventional tx compression

$\sigma_a \uparrow$ $\sigma_r -$

RTC: reduced tx compression

$\sigma_a -$ $\sigma_r \downarrow$

TC: tx compression

$\sigma_a \uparrow$ $\sigma_r \downarrow$

CTE: conventional tx extension

$\sigma_a -$ $\sigma_r \uparrow$

RTE: reduced tx extension


$\sigma_a \downarrow$ $\sigma_r -$

TE: tx extension

$\sigma_a \downarrow$ $\sigma_r \uparrow$


How to reproduce stress paths in laboratory

CTC test : shearing with $\sigma_a \uparrow$ and $\sigma_r -$



How to reproduce stress paths in laboratory

CTC test : shearing in **DRAINED CONDITIONS**



During shearing (stage 2):


- $p_w = p_{w,0} \rightarrow \Delta p_w = 0$
- $p' = p$ if $p_{w,0} = 0$
- $\epsilon_{vol} \neq 0$

➔
 water flow
 $\Delta V = - \Delta V_w$

- the specimen experiences variation in height (H) and diameter (area, A)
- ΔH is measured $\rightarrow \epsilon_a$
- $A = \frac{V_0 + \Delta V}{H_0 + \Delta H} \rightarrow \sigma_a$

How to reproduce stress paths in laboratory

CTC test : shearing in **UNDRAINED CONDITIONS**



During shearing (stage 2):

- $p_w \neq p_{w,0} \rightarrow \Delta p_w \neq 0$
- $p' \neq p$
- $\varepsilon_{vol} = 0$


water flow
 $\Delta V = -\Delta V_w = 0$

- the specimen experiences variation in height (H) and diameter (area, A) but no volume changes
- ΔH is measured $\rightarrow \varepsilon_a$
- $A = \frac{V_0 + \Delta V}{H_0 + \Delta H} \rightarrow \sigma_a$


How to reproduce stress paths in laboratory

CTC test : shearing in **UNDRAINED CONDITIONS**

Δp_w , for a given total stress change, mainly depends on the compressibility of the solid skeleton and of the fluids within the specimen.



The soil element is originally in equilibrium under a stress state (p)



Total stress is modified with changes in principal stresses. The application of the total stresses can be considered as taking place in two stages

How to reproduce stress paths in laboratory

CTC test : shearing in **UNDRAINED CONDITIONS**

The change in pwp occurring under changes in total stresses must be known in problems involving undrained conditions.

Skempton (1954) derives the following expression:

$$\Delta u_w = B \left[\Delta \sigma_3 + A(\Delta \sigma_1 - \Delta \sigma_3) \right]$$

A and **B** are the pore-pressure coefficients, measured in the lab for changes in principal total stresses occurring in the problem under analysis.

B accounts for isotropic stress changes.

A accounts for deviator loadings.

VALUES OF PARAMETER <i>A</i>			VALUES OF PARAMETER <i>B</i>				
Material (<i>S</i> = 100%)	<i>A</i> (at failure)	Reference	Material	<i>S</i> (%)	<i>B</i>	Reference	
Very loose fine sand	2 to 3	Typical values given by Bjerrum	Sandstone	100	0.286	Computed from compressibilities given by Skempton (1961)	
Sensitive clay	1.5 to 2.5		Granite	100	0.342		
Normally consolidated clay	0.7 to 1.3		Marble	100	0.550		
Lightly overconsolidated clay	0.3 to 0.7		Concrete	100	0.582		
Heavily overconsolidated clay	-0.5 to 0		Dense sand	100	0.9921		
	<i>A</i>		Loose sand	100	0.9984		
Material (<i>S</i> = 100%)	(for foundation settlement)	Reference	London clay (OC)	100	0.9981		
Very sensitive soft clays	>1	From Skempton and Bjerrum (1957)	Gosport clay (NC)	100	0.9998		
Normally consolidated clays	½ to 1		Vicksburg buckshot clay	100	0.9990		M.I.T.
Overconsolidated clays	¼ to ½		Kawasaki clay	100	0.9988 to 0.9996		M.I.T.
Heavily overconsolidated sandy clays	0 to ¼		Boulder clay	93	0.69	Measured by Skempton (1954)	
				87	0.33		
				76	0.10		

Values reported by Lambe and Whitman (1969)

How to reproduce stress paths in laboratory



To do @ home

Assume a fully saturated and ideal-elastic geomaterial. During the shearing phase of a CTC triaxial test ($\Delta\sigma_3 = 0$) in undrained conditions, how will evolve the pore pressure (Δp_w) with respect to the axial stress $\Delta\sigma_1$? Illustrate in a $q - p'$ (p) plane

Hint: use Skempton's formula


Stress paths

Practical example of the path reproduced by a CTC test




Stress paths

Example of outputs of a CTC test – **DRAINED CONDITION** with $p_{w,0} = 0$



Stress paths




Example of outputs of a CTC test – **UNDRAINED CONDITION** with $p_{w,0} = 0$



Stress paths

RTE test : shearing with $\sigma_a \downarrow$ and $\sigma_r -$

Practical example of the path reproduced by a RTE test



Conclusions

- Effective stress – a tool to go from multi-phase description to single phase continuum description
- Stress-path strictly depends on the problem under consideration
- Reproduction of stress path using triaxial test as a general framework

Thank you for your attention

